



1 Glue ribs W-11 and W-12 into the notches in the trailing edge W-1 and leading edge W-3. Place W-2 spruce spars into the notches in the ribs.

F-12 Balsa